TECHNICAL BULLETIN

TB0013

Applications: Ford 2.2 & 2.4 Duratorq

BOLT TORQUE SETTINGS

Best Practice:

After installation, stamp the damper pulley bolt head with a centre punch to indicate usage.
The bolts should be tightened in 2 stages

Stage 1: 30 Nm
Stage 2: +90 degrees



Damper pulley retaining bolts must only be used 3 times

FAI products are designed for use in standard, unmodified vehicles and are not intended for custom or altered applications. All components must be installed by a qualified technician.

Please note: FAI products are supplied without fitting instructions.